

OPERATOR'S MANUAL & PARTS LIST



RIDING MOWER MODELS 226VG4

THE GRASSHOPPER COMPANY
Moundridge, Kansas 67107 U.S.A.
(620) 345-8621
GRASSHOPPERMOWER.COM



172103-220122

Printed in U.S.A.

INTRODUCTION

Congratulations on your selection of Grasshopper equipment. We believe you have exercised excellent judgment in the purchase of Grasshopper equipment. We are most appreciative of your patronage.

We recommend that you carefully read this entire manual before operating the unit. Time spent becoming fully acquainted with its performance features, adjustments and maintenance will add a longer and more satisfactory life to your Grasshopper.

The Grasshopper equipment you have purchased has been carefully engineered and manufactured to provide dependable and satisfactory use. Like all mechanical products it will require cleaning and upkeep. Lubricate it as specified in the manual. Observe all safety information in this manual and all safety decals on the tractor and attachments.

The illustrations and data used in this manual were current at the time of printing, but due to possible in-line production changes your machine may vary slightly in detail. The manufacturer reserves the right to make changes or add improvements to its products at any time without incurring any obligation to make such changes to products manufactured previously.

As with all lawn and grounds equipment, if handled carelessly this machine is a dangerous piece of equipment. **If used incorrectly this machine can cause severe injury.** You, the operator, are responsible when operating it. Therefore, safety is of the utmost importance.

Safety & Operation video
To view the video, scan the QR code or enter the web address

English 

Spanish 

English www.grasshoppermower.com/safeops

Spanish www.grasshoppermower.com/safeops_span

"EMISSION CONTROL INFORMATION"
THIS EQUIPMENT MEETS 2022 U.S.
EPA EVAP STANDARDS: 40 CFR PART 1060
FOR NONROAD EQUIPMENT.
EVAPORATIVE EMISSIONS FAMILY: NMRMPNHEQGH1
MFG'D BY: MORIDGE MANUFACTURING INC.

JAN	FEB	MAR	APR	MAY	JUN	2022
JUL	AUG	SEP	OCT	NOV	DEC	

165310

Part No. 165310

ATTENTION:

- Read the instructions and warnings carefully before using this machine.
- Read your Grasshopper warranty enclosed with the tractor manual. To validate warranty, fill in the required information and return the warranty form within 10 days of purchase to:

THE GRASSHOPPER CO.
P.O. Box 637
Moundridge, Kansas 67107

Use only genuine Grasshopper service parts. Substitute parts will void the warranty and may not meet standards required for safe and satisfactory operation. Record the model and serial number of your mower.

MODEL: _____

SERIAL NUMBER: _____
(Serial tag is located tractor frame bottom, left of engine.)

Provide this information to your dealer to obtain correct repair parts.

FindAGrasshopperDealer.com

IMPORTANT: This equipment is equipped with an evaporative emission control system (EECS) as required by the US Environmental Protection Agency (EPA). The EECS includes the carburetor, fuel tank(s), fuel hoses, fuel cap(s), valve(s), vapor hoses, filters, clamps, and connectors. These parts should be maintained properly and replaced as needed. **DO NOT** remove, or modify any part of the EECS.

IMPORTANT: This equipment **DOES NOT** meet the requirements of the California Air Resources Board (CARB) for evaporative emissions. **DO NOT** operate this equipment in the State of California.

IMPORTANT: This engine is not equipped with a spark arrester muffler. It is a violation of California Public Resource Code Section 4442 to use or operate the engine on any forest-covered, brush-covered or grass-covered land. Other states or federal areas may have similar laws.

The enclosed *Engine Owner's Manual* is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of exhaust emission systems, maintenance and warranty. Replacements may be ordered through the engine manufacturer.

WARNING

Engine exhaust, and certain components of this product contain or emit chemicals known to the state of California to cause cancer, birth defects and other reproductive harm. www.P65Warnings.ca.gov

Copyright © 2022-2018 by The Grasshopper Company. All rights reserved.

TABLE OF CONTENTS

	PAGE
SPECIFICATIONS	5
SAFETY SYMBOLS	6
SAFETY DECALS	7
SAFETY INFORMATION	
Training	8
Preparation.....	8
Fuel Handling Safety.....	8
Filling the Fuel Tank	9
Operational Safety	9
Maintenance Safety	10
Storing Safely.....	11
GENERAL INFORMATION	
General Information	12
Measurement Conversion	13
Bolt Size and Tightening Recommendations	13
OPERATION	
Controls and Switches	14
Pre-start Check List.....	15
Mounting and Dismounting the Mower.....	17
Starting the Engine.....	17
Cold Weather Starting Tips	17
Steering Lever Operation	17
Cutting Height Adjustment.....	20
Mowing	20
Blades	21
Uneven Terrain	22
Stopping the Engine.....	22
Moving Machine Without Power.....	23
Loading / Transporting Machine.....	23
Storing Safely.....	24
LUBRICATION AND MAINTENANCE	
Lubrication.....	25
Capacities	25
Tire Air Pressure.....	25
Drive System.....	25
Crankcase Oil and Air Filter	25
Cooling System	26
Battery Maintenance	26
Checking Drive System Fluid Level	26

(continued)

TABLE OF CONTENTS - (CONTINUED)

Drive System Fluid and Filter Maintenance	27
Changing Drive System Fluid.....	27
Deck Cleaning.....	28
Blade Inspection.....	28
Blade Sharpening.....	28
Blade Removal.....	29
Blade Installation.....	29

ADJUSTMENTS AND TROUBLESHOOTING

Loss of Power in the Drive System	30
Drive Belt Replacement	30
No Positive Neutral Position.....	31
Neutral Adjustment.....	31
Steering Lever Adjustment	32
Engine Troubleshooting	32
Park Brake Adjustment.....	33
Clutch/Brake Burnishing.....	33
Clutch Removal/Replacement.....	33
Mower Deck Leveling Adjustment	34
Mower Deck Cut Height Setting Adjustment	35
Deck Belt Adjustment	36
Deck Belt Replacement.....	37
Blade Spindle Assembly Removal	38
Blade Spindle Assembly Repair/Replacement.....	38

PARTS LIST AND ILLUSTRATION

Tractor Assembly.....	40
Drive & Steering Assembly.....	42
ROPS & Seat Assembly	44
Brakes Assembly & Expansion Tanks	46
Wiring Diagram	48
Deck Carrier Linkage	50
Deck Assembly - Model 226VG4/52	52
Deck Assembly - Model 226VG4/52R.....	54
Deck Assembly - Model 226VG4/61	56
Deck Assembly - Model 226VG4/61R.....	58
Blade Spindle Assembly.....	60
Discharge Spindle Assembly.....	61

SPECIFICATIONS

226VG4

Engine Vanguard
two cylinder, 4 cycle, air cooled

Horsepower (G.I.H.P.) * 26 (19.4 kw)
Displacement 49.4 cu. in. (810 cc)
No-load r.p.m. 3600
Charging System 12VDC 16 amp. negative ground
Starter Electric
Electrical System Safety interlocked

* Engine Manufacturer's Gross Hp Rating

Deck Drive Electric clutch

Drive System G⁴ dual path hydrostatic direct drive

Steering Dual levers independently control speed and direction of travel. Zero turning radius

Speed

Forward (variable) 0-9.0mph (14.4km/h)
Reverse (variable) 0-6mph (9.6km/h)

Fuel Tank Capacity 6.5 U.S. gal. (24.6 l.)

Tire Sizes

Drive Wheels - 4 ply rated 23 x 10.5 x 12
Front Wheels - 4 ply rated 13 x 6.5 x 6 rib

Dimensions of Tractor

Seat Back Height 46" (1.17 m)
Seat Cushion Height 30" (0.76 m)
Tractor Width 50" (1.27 m)
Tractor Length 76" (1.93 m)
Wheel Base 46" (1.17 m)

	226VG4/52	226VG4/61
Weight - Uncrated	960 lbs (435 kg)	1030 lbs (467 kg)
Weight - Crated	1200 lbs (544 kg)	1270 lbs (576 kg)

Hour Meter Standard

SAFETY SYMBOLS



This Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

Throughout this manual the term **IMPORTANT** is used to indicate that failure to observe can cause damage to equipment. The terms **CAUTION**, **WARNING** and **DANGER** are used in conjunction with the Safety Alert Symbol [a triangle with an exclamation mark] to indicate the degree of hazard for items of personal safety.

CAUTION

Is used for general reminders of good safety practices or to direct attention to unsafe practices.

WARNING

Denotes a specific potential hazard.

DANGER

Denotes the most serious specific potential hazard.

SAFETY DECALS

Replace Immediately If Damaged




Fig. 1

WORK SAFELY - FOLLOW THESE RULES

CAUTION

The designed and tested safety of this machine depends on it being operated within the limitations as explained in this manual. Read manual before operating.

TRAINING

- Safety instructions are important! **READ THIS MANUAL AND ALL SAFETY RULES.**
- Know your controls and how to stop machine, engine and mower deck quickly in an emergency.
- To avoid accident or injury, do not allow anyone to operate this machine without proper instruction. Any person who operates this machine **MUST** be instructed in and capable of the safe operation of the unit and all controls.
- Do not allow children or unqualified individuals to operate machine.

PREPARATION

- Always wear relatively tight and belted clothing to avoid entanglement in moving parts. Wear sturdy, rough soled work shoes. Never operate machine in bare feet, sandals or sneakers.
- This machine produces sound levels in excess of 85 dBA at the operator ear and can cause hearing loss through extended periods of exposure. Wear hearing protection when operating this machine.
- Walk around machine and visually inspect for damaged, loose, or missing components. Do not operate unless all components are properly mounted, adjusted and in good working condition.
- Ensure all safety switches function properly. See Operation section for details.
- Ensure all safety shielding is in good condition and properly installed.
- Ensure either the discharge shield, restriction plate, or complete vacuum attachment is installed.
- Ensure ROPS is in good condition and installed properly. Never modify ROPS with holes, notches or welding. If ROPS is dam-

- aged, it must be replaced.
- Check brake action before you operate. Adjust or service brakes as necessary.
- Ensure all safety decals are installed and in good condition.
- Remove accumulated debris from machine to avoid fire hazard.
- Inspect area to be cut removing stones, branches and other debris that might be thrown causing injury or damage.
- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job.
- Low-hanging branches and similar obstacles can injure the operator or interfere with mowing operation. Before mowing, identify potential obstacles such as low-hanging branches, and trim or remove those obstacles.
- Never permit any person, other than the operator, to ride or board the mower at any time.
- Operate only in daylight or good artificial light.

FUEL HANDLING SAFETY

- In certain conditions, gasoline, ethanol, diesel and other types of fuel are extremely flammable and highly explosive. A fire or explosion from fuel can burn you and others and can damage property.
- Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any fuel that spills.
- Do not remove the fuel cap if the engine or fuel tank is hot. Allow several minutes to cool.
- Remove the fuel cap slowly to release any pressure from the fuel tank.
- Do not fill the fuel tank completely full. Add fuel to the tank until the level is .25" to .5" (6 mm to 13 mm) below the bottom of the filler neck. This empty space in the tank allows fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply of fuel.

- Never store antifreeze or oil in the fuel container.
- Always place fuel containers on the ground away from your vehicle before filling.
- Do not fill fuel containers inside a vehicle or on a truck or trailer bed because interior carpets or plastic truck bed liners may insulate the container and slow the loss of any static charge.
- When practical, remove equipment from the truck or trailer and refuel the equipment with its wheels on the ground.
- If this is not possible, then refuel such equipment on a truck or trailer from a portable container, rather than from a fuel dispenser nozzle.
- If a fuel dispenser nozzle must be used, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.
- Never use cellular phones or other portable electronic devices when handling fuel.

FILLING THE FUEL TANK

- Always fill the fuel tank with the machine parked on a hard LEVEL surface with the engine stopped, the park brake set, and the key removed from the ignition.
- Do not fill the fuel tank completely full. Air space is required in the full tank to allow the fuel to expand and contract with temperature changes. A valve is located in the top center of the tank to allow air to enter and exit the tank.
- Never remove the fuel cap or fill the fuel tank when the engine is hot. Allow several minutes to cool.
- Filling the fuel tank, with the machine parked on a slope, can cause you to over fill the tank.

OPERATIONAL SAFETY

- Read “Operation” section of this manual before attempting to operate this unit.
- Do not operate without ROPS deployed.
- Fenders serve as shields. Do not operate without them.
- DO NOT drive machine without mower deck installed. The proper stability of the

machine depends on the weight of the mower deck.

- Keep bystanders away from equipment while it is in operation.
- Keep children and pets a safe distance away. Never direct discharge toward anyone.
- Start engine from operator’s seat after disengaging PTO and placing steering levers into the swing-out (neutral lock) position.
- Keep hands and feet away from underneath mower deck while engine is running. Stay clear of all moving parts on machine.
- Wear suitable hearing protection when operating this machine.
- Do not operate in reverse unless absolutely necessary and then only after careful observation of the entire area behind you.
- If operator must dismount to make adjustments the engine must not be running.
- If machine is equipped with a fixed ROPS, always wear seatbelt.
- If machine is equipped with a foldable ROPS, always wear seatbelt when ROPS is deployed.
- When foldable ROPS must be down (i.e. loading or unloading on an enclosed trailer), DO NOT use seatbelt and drive with extra care.
- Do not move steering levers from forward to reverse or reverse to forward position rapidly. The sudden direction change could cause loss of control.
- Do not operate on steep slopes.
- Do not stop, start or change directions suddenly on slopes.
- Use extreme care and maintain minimum ground speed when traveling or operating on a slope, over rough ground, or when operating close to ditches and fences.
- Reduce speed on slopes and sharp turns to minimize tipping and avoid loss of control. Be careful when changing directions on slopes.
- Stay alert for holes, rocks, roots and other hidden hazards in the terrain. Keep away from drop-offs and soft embankments.
- Stop machine and mower deck immediately upon striking an obstruction. Turn engine off, inspect machine and mower deck. Repair any damage before resum-

ing operation.

- Disengage PTO, stop engine, set park brake, remove key and wait for all movement to stop before dismounting, making adjustments, cleaning, or unclogging the machine.
- Never transport mower with blades running. Disengage PTO before crossing streets, sidewalks, driveways, etc.
- Watch for traffic when operating near or crossing roadways.
- This machine is not equipped for highway use, especially when safety lighting and marking is required. It is not a recreational vehicle.
- This unit is not equipped with a drawbar. Do not pull loads.
- Take all possible precautions when leaving machine unattended: disengage PTO, lower mower deck, place steering levers in neutral, set parking brake, stop engine and remove key from ignition.
- Never carry passengers.
- Do not run engine in an enclosed area without adequate ventilation. Exhaust gases contain carbon monoxide, an odorless and deadly poison.

MAINTENANCE SAFETY

- Always perform maintenance with the machine parked on a hard level surface; with the engine stopped and the PTO disengaged; with the park brake set; and with the key removed from the ignition.
- Always remove the grounded (-) clamp from the battery when performing maintenance on the engine, clutch, or any other electrical system. Battery is located under the left fender.
- Always wear close fitting clothing and safety equipment appropriate for the job. Keep work area clean and dry.
- Never work under the machine without jack stands or other equivalent safety blocks. Do NOT rely solely on mechanical or hydraulic jacks or lifts for support. Always use adequate wheel chocks on tires remaining on the ground.
- Never work under the attachment with-

out holding it in the upright position with chains or straps or blocking underneath the deck. Do NOT rely solely on the electric or hydraulic system.

- Hydraulic hoses can fail due to physical damage, kinks, age, and exposure. Check hoses regularly. Replace damaged hoses.
- Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.
- Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.
- If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension. If an exhaust pipe extension is not available, work near open doors and get outside air into the area.
- Waste products such as used oil, fuel, coolant, and batteries can harm the environment and people. Dispose of waste products properly.
- Never attempt to disconnect or alter any part of the safety interlock systems.
- Do not change engine governor settings.
- Keep engine free of grass, leaves, or excess grease to reduce fire hazard and minimize engine overheating.
- Keep machine and mower deck in good operating condition and all safety devices in place.
- Periodically tighten all bolts, nuts and screws. Check that all locking pins are properly installed and in good condition.
- Check brake operation frequently. Adjust and service as required.

STORING SAFELY

- Never store machine with fuel in the tank inside a building where fumes may reach an open flame, spark or pilot light as on a furnace, water heater, clothes dryer, or

other gas appliance. Allow engine to cool before storing in an enclosure.

- If engine is to be unused for 30 days or more, add a fuel stabilizer to the fuel system. Fuel stabilizer (such as STA.BIL[®]) is an acceptable additive in minimizing the formation of fuel gum deposits during storage. Add stabilizer to fuel in fuel tank or storage container. Always follow mix ratio found on stabilizer container. Run engine at least 10 minutes after adding stabilizer to allow it to reach the carburetor or injectors.
- If draining fuel tank, drain fuel into an approved container outdoors and away from open flame.
- Always provide adequate ventilation when running engine indoors. Exhaust gases contain carbon monoxide, an odorless and deadly poison.
- Never store an attachment in the raised position without securing the attachment with chains or straps or blocking underneath the attachment. It is best to remove attachment from tractor. Remove all accumulated debris from attachments and tractor.
- Clean machine with air or cloths. DO NOT high pressure wash. Never clean hot components with cold water.
- Sand areas where paint is chipped and repaint to prevent rust. Lubricate all locations to prevent moisture damage during storage.

GENERAL INFORMATION


The purpose of this manual is to assist the operator in maintaining and operating **GRASSHOPPER** mowers. Read it carefully. It furnishes information and instructions that will help you achieve years of dependable performance.

These operating and maintenance instructions have been compiled from extensive field experience and engineering data. Some information may be general in nature due to unknown and varying conditions. However, through practice and these instructions you should be able to develop operating procedures suitable to your particular situation.

The illustrations and data used in this manual were current at the time of printing, but due to possible in-line production changes, your machine may vary slightly in detail. **GRASSHOPPER** reserves the right to redesign and change the machine as necessary without notification.

WARNING

Some illustrations in this manual show the machinery with safety shields removed to provide a better view. The machine should never be operated with any safety shielding removed.



Throughout this manual, references are made to right and left directions. These are determined by standing at the rear of the equipment and facing the direction of forward travel.

Mower blade rotation is clockwise as viewed from the top of mower.

MEASUREMENT CONVERSION


Measurements expressed in this manual are decimal values. Use the chart below if you are unsure of a measurement to obtain the fractional equivalent.

Conversion Table - Inches			
Decimal	Fraction	Decimal	Fraction
0.062	1/16	0.562	9/16
0.125	1/8	0.625	5/8
0.187	3/16	0.687	11/16
0.250	1/4	0.750	3/4
0.312	5/16	0.812	13/16
0.375	3/8	0.875	7/8
0.437	7/16	0.937	15/16
0.500	1/2	1.000	1


BOLT SIZE AND TIGHTENING RECOMMENDATIONS

The chart below lists the correct tightening torque for bolts used on Grasshopper machinery. When bolts are to be tightened or replaced refer to this chart to determine the grade of bolt and proper torque (*except when specific torque values are assigned in the manual text*).


Bolt Head Markings



SAE Grade 2
(no dashes)



SAE Grade 5
(3 radial dashes)



SAE Grade 8
(6 radial dashes)

Recommended Torque in Foot Pounds				
Bolt Diameter in Inches				
Decimal	Fraction	SAE Grade 2	SAE Grade 5	SAE Grade 8
0.250	1/4	6	11	14
0.312	5/16	13	21	25
0.375	3/8	23	38	55
0.437	7/16	37	55	80
0.500	1/2	57	85	120
0.562	9/16	82	125	180
0.625	5/8	111	175	230
0.750	3/4	200	300	440
0.875	7/8	280	450	720
1.000	1	350	680	1035

OPERATION

The safe operation of this machine is the responsibility of the operator. Any person who operates the machine **MUST** be instructed in and capable of the safe operation of the machine and all controls. Read all safety information on pages 6 through 11.

CONTROLS AND SWITCHES

(Refer to Fig. 3)

Know your controls and how to stop the machine, engine, and mower deck quickly in an emergency. Do not operate this machine until you are completely familiar with the controls and comfortable with your ability. We recommend you practice in a flat open area at half throttle until you are comfortable with all the controls.

The two **Steering Levers** control speed, motion, and direction of the machine and are located on each side of the seat. The left lever controls flow of hydraulic oil from the left pump to the left drive wheel motor. The right lever controls flow of hydraulic oil from the right pump to the right drive wheel motor. This allows left and right drive wheels to turn independently, which provides the “zero turn” ability. Each lever has two positions: The swung “out” neutral lock position, where the lever will not activate the pump; and the swung “in” operation position, where the lever will activate the pump. For details of steering lever operation, refer to the “Steering Lever Operation” section, page 17-19.

The following controls are located on or beside the Operator’s Console which is located to the right side of the seat.

- The **Ignition Switch** (A) is the key switch located on the console. The ignition switch is used to start and stop the engine. The switch has three positions OFF, RUN, and START. Insert the key into the switch and rotate clockwise to the RUN position. The **Brake Light** (B) should be on at this point. Rotate the switch clockwise to the next (START) position to engage the engine starter (key must be held against spring pressure in this position).
- The **Oil Light** (C) is the indicator light located in the console below the ignition key and labeled “OIL”. This light is connected to the engine oil sender and comes on when oil pressure is below engine’s manufacturer specified level. The oil light comes on when ignition switch is in RUN and START positions and should go off when engine starts and oil pressure reaches specified level.
- The **Choke Control** (D) is the small black push/pull knob located on the throttle. The choke is used to aid in starting a cold engine. Pull the choke knob “up” to activate the choke on the engine. Push the choke knob “down” for the choke to be off. **DO NOT** run a warm engine with the choke on.
- The **Throttle Control** (E) is the large black lever located beside the console to the right of the seat. The throttle is used to control engine speed. Move the throttle lever forward to increase engine speed and rearward to decrease engine speed.
- The **PTO switch** (F) is the red push/pull knob located on the console. Pull PTO knob “up” to engage the electric clutch that drives the belt connected to the mower deck that drives the cutting blades. Push the PTO knob “down” to disengage the electric clutch that stops the blades from turning within a few seconds.
- The **Hour Meter** (G) is the number indicator located on the console. The electric hour meter is connected to the ignition circuit and is provided to record the number of hours the engine runs. If the ignition switch is left on, without the engine running, the hour meter will continue to record.

The **Park Brake Lever** is the lever located on the left side of the footrest. The brake lever engages a brake internal to the transmissions. Pull the brake lever up and rearward until the lever over centers and locks to set the brakes “on”. Push the brake lever forward and down to release the brakes “off”.

Several **Safety Switches** are incorporated in this machine’s design to prevent the engine

from being started in certain conditions and to kill the running engine in certain conditions. These circuits should be checked before each operation to ensure they are working properly. See page 16 for check list on these circuits.

The **Start Circuits** will keep engine from starting unless:


- Both steering levers are swung out in their neutral locked position, and
- The PTO switch is down in it's disengaged position.

The **Kill Circuits** will stop the running engine if:

- The operator raises off the seat any time during operation of the machine with PTO engaged or steering levers in operating position.
- The steering levers are in their operating position and the park brake lever is moved into engaged locked (up) position.
- The park brake is set and the steering levers are moved into their operating position.
- The operator is off the seat and the steering levers are moved into their operating position.
- The operator is off the seat and the PTO switch knob is pulled up to its engaged position.

WARNING

Do not operate this machine unless all safety systems are working properly as described above.



PRE-START CHECK LIST

Maintain desirable operational standards and help ensure the safety of the operator by routinely checking the following on a daily basis:

- Walk around the machine and visually check for loose or missing components. Make sure all components are mounted properly and are in good working condition.
- Make sure all fenders, guards and shields are safely and securely attached.
- Make sure the discharge shield or restriction plate is installed at the discharge opening on the mower deck.
- Make sure all safety decals are clearly readable (see page 7).
- Check hydrostatic transmission fluid level. **DO NOT** operate machine with low fluid. Low fluid could cause damage to transmission and loss of control of the machine.
- Check engine oil level (refer to “Engine Manual” for proper level and type of oil used).

CAUTION

Never attempt to check oil while engine is running.

- Check for oil and fuel leaks.
- Check air cleaner (refer to “Engine Manual”). When mowing in dusty conditions, dry grass or long grass, it may be necessary to remove and clean air intake on the air cleaner.
- Make sure the engine is free of dirt and debris.
- Check fuel level. Refer to “Engine Manual” for correct fuel for your requirements.
- For best results, use only clean, fresh, unleaded gasoline with an octane rating of 87 or higher ((R+M)/2 rating method).
- **Do Not** use ethanol blends of gasoline (such as E15 or E85) with more than 10% ethanol by volume. Performance problems and/or engine damage may result which may not be covered under warranty.
- **Do Not** use gasoline containing methanol.

 DANGER

Do not fill fuel tank while engine is running. Allow engine to cool several minutes before adding fuel. If fuel is spilled, do not start engine and avoid creating a source of ignition until the fuel is wiped clean and evaporated.

- Check tire pressure (see page 25). Improper pressure will adversely affect traction, steering and level cutting height.
- Check tires for damage or cracking.
- Check hydrostatic pump drive belt for damage or cracking.
- Check mower deck belt for damage or cracking.

- Check mower deck level.
- Check to ensure blades are sharp and secure; the cutting edge should be positioned in the direction of blade rotation (clockwise as viewed from top of mower deck).
- Adjust cutting height if necessary.
- Check operation of park brake (see "Park Brake Adjustment" page 33).
- Remove grass and debris from machine.
- Test safety interlock systems (see chart below). Perform these tests in a clear open area and keep bystanders away. If there is a malfunction during one of these procedures, DO NOT operate machine. (See your Grasshopper dealer).

Test Safety Interlock System Daily

Action	Left Steering Lever	Right Steering Lever	PTO Switch	Parking Brake	Proper Result
Start Circuits					
Try starting engine	Out	Out	Off	On	Engine Cranks
Try starting engine	In	Out	Off	On	Engine will not crank
Try starting engine	Out	In	Off	On	Engine will not crank
Try starting engine	Out	Out	On	On	Engine will not crank
Kill Circuits (with engine running at 1/2 throttle)					
Raise off seat	Out	Out	Off	On	Engine does not stop
Raise off seat	In	Out	Off	Off	Engine Stops
Raise off seat	Out	In	Off	Off	Engine Stops
Raise off seat	Out	Out	On	On	Engine Stops
Move left steering lever in		Out	Off	On	Engine Stops
Move right steering lever in	Out		Off	On	Engine Stops

MOUNTING AND DISMOUNTING THE MOWER

Always mount and dismount the mower from the left side, with the brake on, the PTO disengaged (down), the engine off, and the steering levers in their swung out (neutral lock) position. Mount the mower by stepping from the ground to the left side of the deck with your left foot, then step over the deck carrier frame to the footrest with your right foot. Wait for all moving parts to stop before dismounting. Dismount the mower by standing up on the footrest, then turn to the left and step from the footrest, over the deck carrier frame, to the left side of the deck with your right foot, and then step to the ground with your left foot. The left steering lever can be used to stabilize your movement; however, it is not strong enough to support all your weight. Never leave the mower unattended with the key in the ignition.

STARTING THE ENGINE

DANGER

Never start the engine in confined rooms. Exhaust gases contain carbon monoxide, an odorless and deadly poison.

Do not allow children to approach the machine while the engine is running.

Do not operate the machine around open flames such as trash fires.

Do not operate the engine when an odor of fuel is present or other explosive conditions exist.

- Position yourself on the tractor seat.
- Engage the park brake.
- Place both steering levers in swing-out neutral position.
- Place electric clutch switch in “OFF” (down) position.
- Set the throttle at 1/3 open.
- Insert the key into the ignition switch and turn to “RUN” position.
- Check to see that the brake lamp is on.

- Turn the key to “START” position. Choke as necessary to start. When engine starts, release key immediately. Push choke knob down gradually until choke is completely off and engine is running smoothly.
- Warm the engine up at medium speed for several minutes.

You will enhance the starter life by using short starting cycles of several seconds. Engaging starter motor more than 15 seconds per minute can result in damage to starter.

COLD WEATHER STARTING TIPS

Use proper viscosity oil for temperature expected (see “Engine Manual”).

Set throttle at half open.

A warm battery has better starting capacity than a cold one.

Use fresh winter grade fuel. It is better for winter starting than leftover summer grade fuel.

STEERING LEVER OPERATION

(Refer to page 19, Fig. 4)

WARNING

Do not move steering levers from forward to reverse or reverse to forward position rapidly. Sudden direction changes could cause loss of control or damage the machine.

CAUTION

Help prevent personal injury. Learn use of the steering levers and practice at half throttle until becoming proficient and comfortable with the operation of the machine.

The steering levers control speed, motion and direction of the machine. The steering levers have two positions: (1) **Neutral Lock**, where the lever(s) are swung completely outward and cannot be moved fore and aft; (2) **Operating**, where the lever(s) are swung in and can be moved fore and aft.

Neutral Lock Position:

- Forward and reverse movement of the motion control levers is prevented when levers are in the swung out (neutral lock) position. Machine should not move with the steering levers in the swung out (neutral lock) position and the park brake released. If machine does move, see “Neutral Adjustment” section page 31.
- Steering levers must be in the swung out (neutral lock) position to start the engine.
- Steering levers must be in the swung out (neutral lock) position to safely enter and exit the operator seat.
- Operator can exit mower with the engine running when the steering levers are in the swung out (neutral lock) position, PTO switch is disengaged, and the park brake is engaged.

Operating Position:

- Machine speed, motion and direction can be controlled when the engine is running, park brake is released, and steering levers are in the swung in (operating) position.

Neutral

- When the steering levers are swung in and centered fore and aft, they are in operating (neutral). In operating (neutral), the hydrostatic pumps do not deliver fluid to the wheel motors.

Forward and Reverse Motion:

- Pushing both levers forward at the same time will move the machine forward.
- Pulling both levers to the rear at the same time will move the machine in reverse.
- The further forward or rearward the steering levers are moved, the faster the machine will move in that direction.

Turning:

- While moving forward, turn gently right by pushing the left lever further forward than the right.
- While moving forward, turn gently left by pushing the right lever further forward than the left.
- Make a sharp turn right by pushing the left lever forward and pulling the right lever rearward at the same time.

- Make a sharp turn left by pushing the right lever forward and pulling the left lever rearward at the same time.
- DO NOT turn the machine by leaving one lever in neutral and moving the other lever. This will cause damage to the turf under the tire that is not rotating.

Stopping:

- To stop motion, move both steering levers back to neutral. Machine is equipped with springs to automatically return both levers to neutral. If levers do not automatically return to neutral, see your authorized Grasshopper dealer for adjustment.

IMPORTANT







If you become confused during operation, release both steering levers. They will automatically return to the centered neutral position and the machine will stop.

IMPORTANT

Inspect hydrostatic drive belt(s) daily. DO NOT operate on steep slopes. DO NOT operate near drop offs or embankments.

Since hydrostatic drive systems are a direct, hydraulic connection to the drive wheels, they provide a means of braking during operation. If the hydrostatic drive system belt breaks or comes off, the system no longer provides any control. In this condition, return steering levers to the swing out, neutral position and apply the parking brake. The pumps (in the neutral position) will provide the most resistance to the drive wheels. Do not move the steering levers from the swung out, neutral position, as this will open passage ways in the pumps and freewheeling can occur.

STEERING LEVER OPERATION



07033B

Fig. 4

CUTTING HEIGHT ADJUSTMENT

(Refer to Fig. 5)

1. The mower deck cutting height adjustment mechanism is located to the right front of the operator seat on the deck carrier frame.
2. When adjusting cutting height always come to a complete stop, disengage (down) the PTO and wait for blades to stop rotating.
3. Pushing down on the foot lever (A) with your foot will raise the deck and take pressure off the height adjustment pin (B).
4. To change cutting height, push down on the foot lever (A) and rotate the deck latch (F) behind the latch tube guide (E) to support the deck. This puts the deck in the transport (5 inch cut) height position.
5. With the deck supported by the deck latch (F), place the height adjustment pin (B) in the hole indicated by the cutting height decal for the desired cutting height.
6. To set the deck at this cut height, push down on the foot lever (A) until pressure on the deck latch (F) is released and lift the deck latch (F) out from behind the latch tube guide (E). Then slowly decrease pressure on the foot lever (A) to allow the deck to lower and the adjustment tube (C) to move backward through the latch tube guide (E) until the height adjustment pin (B) contacts the end of the latch tube guide (E) and supports the deck.
7. Holes provided in the adjustment tube (C) allow for cutting height adjustment in 1/2 inch increments. A height adjustment spacer (D) is provided to allow for cutting height adjustment in .25 inch increments.
8. To set cutting height at a .25 inch increment, the height adjustment spacer (D) should be located between the height adjustment pin (B) and the end of the latch tube guide (E).
9. To set the cutting height at a .5 inch increment, the height adjustment spacer (D) should be located forward of the height adjustment pin (B).




Fig. 5

MOWING

WARNING

Walk area before mowing, picking up all rocks, twigs and other debris. Enter new areas carefully. Cut grass higher the first time to allow mower to clear unseen objects. Never assume an area is clear - always check!

Clear mowing area of all people when operating mower. Thrown objects could injure bystanders.

WARNING

Before starting to mow, position the machine in the area to be mowed with the mower deck set at the desired cutting height. With the engine at full throttle, pull up on the PTO switch knob to start the blades turning.

DANGER

To avoid serious injury or death from thrown objects or contact with blades, NEVER operate mower without discharge shield or restriction plate installed.

Keep hands and feet away from discharge opening.

Before mowing, analyze the area to determine the best mowing procedure. Consider height, type of grass and terrain type (rolling, level or rough).

Proper ground speed for mowing will depend on the height, type and density of grass to be cut. Normally, ground speed will range from three to six miles per hour. Tall dense grass should be mowed at a low speed, while thin medium height grass can be cut at a faster ground speed. Always operate engine at full governed rpm when mowing. This is necessary to maintain proper blade speed to produce a clean cut.

Follow local recommendations for the suitable cutting height in your area. Avoid mowing grass too short to increase mowing intervals. This may stress the grass during hot weather and encourage weed growth during the growing season.

Mow with uncut grass to the left. This will distribute the clippings over the cut area. Discharging clippings over the uncut area will cause a grass buildup and may prevent uniform cutting.

Remember that sharp blades produce cleaner cuts and use less power.

Extremely tall grass should be mowed twice. Cut grass higher on first pass. Cut the second time at desired height and 90° to the first pass.

BLADES

HI-LOW MULCHING BLADE



Hi-Low mulching blades are recommended with the discharge restriction plate and front shrouds installed (down discharge mulching option).

MEDIUM LIFT BLADE




Medium lift blades are recommended when the optional vacuum attachment is installed.

CONTOUR BLADE



Contour blades are designed for operation with the side discharge shield and may be used when the optional vacuum attachment is installed.

HIGH LIFT NOTCHED BLADE



High lift notched blades should be used when the side discharge shield has been installed. These blades are recommended for mowing tall and/or lush areas.

Fig. 6

UNEVEN TERRAIN

WARNING

Be careful when operating mower on uneven ground.

Do not operate on steep slopes. Operation on a steep slope could cause loss of control, machine to overturn and personal injury or death.

- Do not operate on steep slopes. This machine was not specifically designed to operate on steep slopes.
- The operator is responsible for safe operation on slopes. Only the operator can determine the stability of the mower on a given slope based on existing conditions like: machine speed and direction, slope variation, slipperiness, drop-offs, holes, obstacles, etc.
- To determine stability on a slope, start at the bottom and try to back the mower up the slope slowly. If you cannot back up the slope or if you feel uneasy on it, do not operate on it.
- Always start mowing at the bottom of slopes. Traveling up slopes, this machine has more traction traveling forward than reverse. Be careful on slopes to avoid driving forward into a position where there is not enough traction to enable backing out or stopping.
- Tires may lose traction on slopes even though the brakes are functioning properly.
- Avoid sudden starts and acceleration when traveling forward uphill as mower may tip backwards.
- Do not mow slopes when grass is wet because slippery conditions will reduce traction and braking which in turn affects steering.
- Use caution when making turns. Slow the mower down before making sharp turns. Unit can spin very rapidly by positioning one lever too much ahead or behind the other.
- Look around you to be sure the area is

clear before turning or backing up.

- Avoid starting or stopping on a slope. If tires lose traction, disengage the blades and proceed slowly straight down the slope.
- Keep all movement on slopes slow and gradual. Do not make sudden changes in speed or direction.
- Follow manufacturer's recommendation for counterweights for added stability when operating on slopes or using front or rear mounted attachments. Remove weights when not required.
- Use extra care with grass catchers or other attachments. These can change the stability of the machine. Do not use grass catcher on steep slopes.
- Do not operate without ROPS deployed.
- If machine is equipped with a fixed ROPS, always wear seatbelt.
- If machine is equipped with a foldable ROPS, always wear seatbelt when ROPS is deployed.
- Be certain that the seatbelt can be released quickly if the machine is driven or rolls into ponds or water.
- Check carefully for overhead clearances such as, branches, doorways, or electrical wires, before driving under any objects and do not contact them.

STOPPING THE ENGINE

- Set the throttle at 1/3 open. Allow engine to idle at this setting for several minutes.
- Move ignition switch to "OFF" position (up-right) and remove key.
- Never use carburetor choke to stop engine.

CAUTION

Always remove key from ignition switch when leaving machine unattended or when not in use.


MOVING MACHINE WITHOUT POWER

(Refer to Fig. 7)

The integrated transmissions are equipped with a bypass valve that allows the machine to be moved without power by deactivating the transmission. With the bypass valve in normal operating position, the fluid in the transmission will make it difficult to move the unit (even with the steering levers in neutral position). The bypass valve is located on the top of each transmission. Before activating the bypass valve, set the park brake. Raise the seat and activate the bypass valve by rotating lever 90°. When BOTH transmissions are deactivated, the unit becomes “freewheeling”, allowing it to be moved. Before the transmissions become operational, the bypass valves must be returned to their normal operating position.

WARNING

Be careful activating bypass valves when machine is on a slope. Machine could “freewheel” out of control causing serious injury or damage to equipment.



LOADING / TRANSPORTING MACHINE


WARNING

Loading a machine onto a trailer or truck increases the possibility of tip-over and could cause serious injury or death.

Use a heavy-duty trailer to transport your machine. Trailer rating must exceed combined weight of machine and attachments. Trailer must have the necessary lights and signs required by law.

1. Park trailer on a hard level surface.
2. Push PTO switch down to the "OFF" position.
3. REVERSE machine onto trailer with mower deck raised to the transport (highest) height position.
 - Use extreme caution when operating machine on a ramp. Move Slowly.
 - Avoid sudden acceleration and deceleration when operating machine on a ramp.
 - Reverse machine up ramp and drive forward down ramp. **DO NOT** attempt to turn machine while on a ramp.
 - Use only a single, full width ramp; **AVOID** individual ramps for each side of the machine.
 - If it is not possible to use one full width ramp, use enough individual ramps tied together to simulate a full width continuous ramp.
 - **DO NOT** exceed a 15 degree angle between ramp and ground or between ramp and trailer or truck.
4. Position machine on trailer for optimal weight distribution (generally slightly forward of trailer axle). Follow tow vehicle and trailer manufacturer guidelines.
5. Stop the engine, engage the park brake and remove the key.
6. Place the height adjustment pin in the bottom (one inch) hole and lower the mower deck to the lowest position.

- Securely fasten machine to trailer with heavy-duty straps, chains or cables. Both front and rear straps must be directed down and outward from machine. Refer to Fig. 8 for suggested tie-down locations.



STORING SAFELY

⚠ CAUTION

Never store machine with gasoline in the tank inside a building where fumes may reach an open flame, spark or pilot light as on a furnace, water heater, clothes dryer, or other gas appliance. Allow engine to cool before storing in an enclosure.

⚠ CAUTION

Never run engine indoors or in an enclosed area, unless exhaust gases are safely removed to the outdoors with an exhaust pipe extension/hose combination. Exhaust gases contain carbon monoxide, an odorless and deadly poison

- If engine is to be unused for 30 days or more, add a fuel stabilizer to the fuel system. Fuel stabilizer (such as STA·BIL®) is an acceptable additive in minimizing the formation of fuel gum deposits during storage. Add stabilizer to gasoline in fuel tank or storage container. Always follow mix ratio found on stabilizer container. Run engine at least 10 minutes after adding stabilizer to allow it to reach the carburetor.
- Remove all accumulated debris from mower deck and tractor.
- Sand areas where paint is chipped and repaint to prevent rust. Lubricate all locations to prevent moisture damage during storage.

LUBRICATION AND MAINTENANCE

⚠ CAUTION

Always perform maintenance with the machine parked on a hard level surface; with the engine stopped and the PTO disengaged; with the park brake set; and with the key removed from the ignition.

⚠ CAUTION

Always remove the grounded (-) clamp from the battery when performing maintenance on the engine, clutch, or any other electrical system. Battery is located under the left fender.

⚠ CAUTION

Always wear safety glasses and ear protection when performing any maintenance function that could cause injury to eyes or ears.

Read all safety information on pages 6 through 11.


LUBRICATION

(Refer to Fig. 9)

Do not let excess grease collect on or around parts, particularly when operating in sandy areas. See accompanying illustrations for lubrication frequency points. Severe or unusual conditions may require more frequent lubrication.

In addition to these lubrication points, lightly oil all linkage pivot points.

Use SAE multipurpose type grease for all locations shown. Be sure to clean fitting thoroughly before using grease gun.



CAPACITIES

Fuel Tank.....6.5 U.S. gal. (24.6 liter)
Drive System.....2.0 U.S. gal. (7.57 liter)
(Each Transmission).....1 U.S. gal (3.78 liter)

TIRE AIR PRESSURE

Drive Tires 23 x 10.5 x 12.....9 psi (55kPa)
(Refer to decal on wheel for correct tire air pressure)
Front Tires 13 x 6.5 x 6.....12 psi (83 kPa)

DRIVE SYSTEM

Fluid Change (1st time).....100 hours
Filter Change (1st time).....100 hours
Every 600 hours thereafter

CRANKCASE OIL AND AIR FILTER

Refer to the "Engine Manual" for the timetable for changing or service.

COOLING SYSTEM

Inspect the engine cooling fins periodically for buildup of grass and debris. Buildup on the cooling fins will cause the engine to overheat.

Removal of engine cowling may be required to clean the fins, especially if cleaned infrequently.

CAUTION

Do not use high-pressure water or steam to clean the engine or drive compartment. Water and cleaning detergent may damage electrical components and terminals, possibly leading to component and safety circuit failure.

Use a vacuum cleaner or air blower to remove foreign material from the engine and drive compartment.

BATTERY MAINTENANCE

Battery is located under the left fender. Follow the procedure below for battery maintenance.


- Clean battery.
- Inspect cables for loose connection.
- Clean terminals.
- Inspect battery tray and hold-down.

WARNING

Batteries contain sulfuric acid. Avoid contact with skin, eyes and clothing. Batteries produce a highly explosive hydrogen gas while being charged. Always keep cigarettes, sparks, open flame and other sources of ignition away from battery. Always shield eyes and face from battery. In the event of accident, flush with water and call a physician immediately. Keep batteries and acid out of the reach of children.


CHECKING DRIVE SYSTEM FLUID LEVEL

Check fluid level when cold, with the engine turned off. The transmission fluid expansion tanks are located, one, under each fender. To check the fluid level, raise the seat and look through the holes in the sides of the frame. The fluid level should be equal to the “Cold Fill Level” line on the expansion tank decal (Refer to Fig. 10). If fluid is required, use CoolTemp Hydro-Max™ Extended-Life Hydrostatic Fluid (Grasshopper part no. 345044 for 1 quart [.94 l] container). To add fluid remove the fender to access the cap on the fluid reservoir.



DRIVE SYSTEM FLUID AND FILTER MAINTENANCE

For Drive System, use CoolTemp Hydro-Max™ Extended-Life Hydrostatic Fluid, part no. 345044 for 1 quart (.94 l) container or part no. 345046 for 2 gallon (7.52 l) container. Use part no. 130205 ZT-4400 filter kit.



CHANGING DRIVE SYSTEM FLUID

(Refer to Fig. 11)

Raise the seat and remove the seat cross member. Place a drip pan under the transmission filter (at the back of the transmission). Remove filter and drain fluid into the pan. Allow transmission to drain completely. Install a new fluid filter. Torque plug to 115-135 in. lbs. Disconnect the hose at the hose fitting in the top of the transmission. Remove the hose fitting and the vent plug next to the hose fitting. Fill transmission with fluid through the hose fitting port. Removing vent plug allows air to escape while filling transmission. Reinstall the vent plug and hose fitting. Reattach the hose from the reservoir to the hose fitting. Let engine idle a few minutes. Add fluid at the expansion tank until fluid is equal to the "cold fill level". Do not overfill, room for expansion of fluid into the expansion tank is required when fluid becomes hot. Repeat procedure for other transmission.

⚠ WARNING

DO NOT operate machine with low fluid. Low fluid could cause damage to drive system and loss of control of the machine.

DECK CLEANING

IMPORTANT

After each use remove grass buildup from under the mower deck. Excessive grass buildup will interfere with the operation and performance of the mower deck. Excessive grass buildup may also cause component failure.

1. Park machine on hard level surface, stop engine and set the park brake. Remove key from the ignition switch.
2. Position the mower deck in the transport (all the way up) setting.
3. Lift the front of the machine, and support the machine using jack stands or other equivalent safety blocks. Do NOT rely solely on mechanical or hydraulic jacks or lifts for support. Always use adequate wheel chocks on tires remaining on the ground.
4. Use a long flat bar to clean under the deck, to avoid positioning yourself under the machine.
5. Clean out all grass and debris build-up from the underside of the deck, around blade spindles and the deck discharge chute.

BLADE INSPECTION

WARNING

Do not handle mower blades with bare hands. Use heavy leather gloves or wrap blade with protective material and block securely when removing blades. Careless or improper handling may result in serious injury.

Inspect blades before each use to determine that they are mounted securely and are in good condition. Replace any blade that is bent, excessively nicked, worn, or has any other damage. Small nicks can be ground out when sharpening.

BLADE SHARPENING

IMPORTANT


When sharpening blades, be sure to balance them. Unbalanced blades will cause excessive vibration that can damage blade spindle bearings. Vibrations may also cause structural cracks in mower housings.

Follow original sharpening pattern. Do not sharpen backside of blade. Do not sharpen blade to a razor edge, but leave approximately .016 inch (.4 mm) blunt edge.

BLADE REMOVAL

(Refer to Fig. 12)

Remove bolt (A), which has right hand threads. Remove washer (B), flat washer (C), fiber washer (D), and blade.



BLADE INSTALLATION

WARNING

Your dealer can supply Grasshopper replacement blades. They are made of special steel alloys and subjected to rigid heat-treat and inspection requirements. Substitute blades may not meet these rigid specifications and **MAY BE DANGEROUS**.

Reverse the removal procedure. Be sure fiber washer and cone are installed as shown.

IMPORTANT

When installing a blade, the lift of the blade must be toward blade spindle housing (refer to Fig. 12). Lubricate bolt threads lightly with a copper based anti-seize. Tighten bolt (item A, Fig. 12) into blade spindle housing to 50-55 ft lbs (68-75Nm).

ADJUSTMENTS AND TROUBLESHOOTING

CAUTION

Always make adjustments with the machined parked on a hard level surface; with the engine stopped and the PTO disengaged; with the park brake set; and with the key removed from the ignition.

CAUTION

Always remove the grounded (-) clamp from the battery when performing maintenance on the engine, clutch, or any other electrical system. Battery is located under the left fender.

LOSS OF POWER IN THE DRIVE SYSTEM

Check the fluid level and make sure the proper amount of fluid is in the reservoir. Make sure all hydraulic connections are tight and not leaking. Make sure drive belt is tight and not slipping. Check park brake adjustment. Make sure pump bypass valve is in the correct position so pump does not freewheel.




Fig. 13

DRIVE BELT REPLACEMENT

(Refer to Fig. 13)

1. Remove the deck belt (A) as described in "Deck Belt Replacement" section (page 37).
2. Remove the clutch center bolt (B) and slide the clutch (C) off the engine's crankshaft.
3. Loosen the .375" idler arm pivot bolt (D) and remove the .312" bolt (E) securing belt tensioner bracket in place. Using a half inch drive break-over bar or racket, inserted in half inch square hole, rotate idler pulley away from belt, relieving belt tension.
4. Remove the belt (F) from pulleys.
5. Install the new belt with the idler tension bracket loose. Using the break-over bar, reinstall the .312" bolt (E) (normally in center hole) in the idler tensioner bracket and secure. Do not over tighten belt, belt should only be tight enough to prevent belt from slipping. Retighten .375 idler arm pivot bolt (D).
6. Install the deck belt as described in "Deck Belt Replacement" section (page 37).


NO POSITIVE NEUTRAL POSITION

If drive wheels travel forward or backward when the steering lever is in swing-out position (neutral), adjustment is required.

NEUTRAL ADJUSTMENT

(Refer to Fig 14)

1. Block up under tractor frame so both drive wheels are off the ground.
2. Make sure parking brake is released.
3. Remove linkage rods (A) from transmission control arm (B).
4. Place steering levers in the neutral swing-out position and start engine.
5. If either of the drive wheels turn, proceed with the following adjustment.
6. With a .25" allen wrench loosen the socket head cap screw (C) directly below the control arm (B). Rotate the neutral return assembly left or right until neutral is achieved. Tighten socket head cap screw.
7. Repeat procedure for transmission on the other side.
8. Reinstall linkage rod (A) in control arm (B). If rod end does not reinstall into neutral return arm without moving the return arm, adjust length of linkage rod until it does to assure neutral adjustment will be maintained when linkage is connected.
9. Test-drive machine for straight-line travel with both levers full forward. If travel is not in a straight line, adjust the steering lever stop on the side that is the fastest, i.e., if machine goes to the left, adjust the right steering stop to slow down the right transmission until travel is straight ahead.






Fig. 15

STEERING LEVER ADJUSTMENT

(Refer to Fig. 15)

To adjust steering levers, loosen 3 prong thumb nuts that secure the upper levers to the lower. This allows the upper levers to be moved backward (refer to Fig. 15). Set levers to a comfortable position for the operator. Hold levers in position and tighten thumb nuts. The levers must line up when in neutral position and maintain a minimum of one inch of clearance between end of levers. If the levers are allowed to lean toward the center when the mounting bolts are tightened, free play in the mounting holes may allow the levers to hit each other.

WARNING

When completing a maintenance function, make sure all shields are in good condition and are installed before placing unit back into use.

ENGINE TROUBLESHOOTING

Should you experience trouble in starting the engine, use the following guide to locate possible causes.

Engine will not crank:

- Battery is discharged.
- Blown starter fuse.
- PTO switch in "ON".
- Steering levers are not out in neutral.
- Steering lever switches are out of adjustment (listen for the switch "click").
- A loose wire or connection.

Engine cranks, but will not start:


- Fuel tank is empty.
- Restricted fuel line or fuel filter.
- A loose wire or connection.

If the above points do not locate the problem, contact your authorized Grasshopper dealer for repair.

PARK BRAKE ADJUSTMENT

(Refer to Fig. 16)

1. Stop engine, wait for all moving parts to stop, and remove key.
2. Disengage the park brake.
3. The park brake lever should take approximately 25-30 lbs of pull to engage brakes.
4. Locate the brake cable assembly underneath the front of the left fender. Adjustment to the length of the brake cable should be made at this point.
5. At the brake cable bracket are two .312" nuts, one on each side of the bracket. To increase the lbs of pull loosen the front nut and tighten the back nut. To decrease the lbs of pull, loosen the back nut and tighten the front nut.
6. If additional adjustment is necessary it can be done at the other end of the brake cable, underneath the tractor.



CLUTCH/BRAKE BURNISHING IMPORTANT


A new clutch, or one that has not been used for three months, will require burnishing to dress drive surfaces. The clutch could fail if you do not accomplish the following procedure.

Place tractor in neutral, start engine and run at half throttle. Turn clutch switch on 30 seconds and off 30 seconds, five times at half-throttle and repeat five times at full throttle. The time interval allows the clutch surface to cool.

CLUTCH REMOVAL/REPLACEMENT

(Refer to Fig. 17)

1. Remove the deck belt (A) as described in "Deck Belt Replacement" section.
2. Remove the center bolt (B) and slide the clutch (C) off the engine crankshaft.
3. To install clutch, reverse order and install deck belt as described in "Deck Belt Replacement" section.
4. Tighten center bolt (B) to 50 ft lbs. After 15 minutes of clutch usage retighten the bolt to 50 ft lbs.



MOWER DECK LEVELING ADJUSTMENT

(Refer to Fig. 18 & 19)

NOTE: The object is to have the mower blades cutting level side to side and cutting slightly lower in the front, with about the same weight on each mower deck hanger chain.

CAUTION

Mower blades are sharp. Wear heavy gloves or cover sharp edges of blades.

1. Check air pressure on all four tires and adjust to the correct pressure if necessary.
2. Mower deck can be leveled at any cut height position. If blade heights do not match cut height setting, do not adjust at this time. Mower deck must be leveled side to side and front to rear before cut height setting is adjusted. See appropriate sections below.
3. Position left blade in the side to side position and measure from the outside blade tip to the level surface (refer to Fig. 18).
4. Position right blade in the side to side position and measure from the outside blade tip to the level surface.
5. If the difference between both measurements is greater than .125 inch, adjustment is necessary.
6. Locate the level adjust screw (A) on the right rear mower deck hanger (refer to Fig. 19).
7. Slightly loosen the .438 chain bolt (C) on the right rear mower deck hanger and level adjust bracket (B).
8. Adjust the right rear of the mower deck up or down as required to match the left rear by turning the level adjust screw (A) clockwise to raise and counter-clockwise to lower.
9. Adjust the level adjust screw (A) until blades on both sides are the same height above the level surface.




Fig. 18





Fig. 19

10. With blades leveled side to side, tighten the .438 chain bolt (C) securely.
11. Position left blade in the front to rear position. Measure from the left front blade tip to the level surface. With the blade in the same position, measure from the left rear blade tip to the level surface.
12. The distance measured at the rear blade tip should be .125 to .25 inch higher than at the front blade tip (Refer to Fig. 20).
13. If the front to rear adjustment is not within the given tolerance, then either adjustment is necessary or the left blade may be bent.
14. Check to see if the left blade is bent by turning it 180° and measure from the left rear blade tip to level surface again. If the result is different by more than .125 inch, the left blade is bent and should be replaced.

15. If the blade is straight and adjustment is necessary, locate the level adjust screw on the left front mower deck hanger.
16. Slightly loosen the .438 chain bolt on the left front mower deck hanger and level adjust bracket.
17. Adjust the left front of the mower deck up or down by turning the level adjust screw clockwise to raise and counter-clockwise to lower until the front blade tip is .125 to .25 inch higher than the rear blade tip.
18. Tighten the .438 chain bolt securely.
19. Repeat steps 11 through 18 above on the right side.
20. Check that each of the mower deck hanger chains (D) are tight and are carrying weight. If a chain is loose, adjust as necessary.



MOWER DECK CUT HEIGHT SETTING ADJUSTMENT

NOTE: Adjust side to side and front to rear mower level before adjusting cut height.


1. Check air pressure on all four tires and adjust to the correct pressure if necessary.
2. With foot pedal, set the cut height at the notch marked 3.
3. Position left blade in the side to side position and measure from the outside blade tip to the level surface (refer to Fig. 20).
4. Position right blade in the side to side position and measure from the outside blade tip to the level surface.
5. If the difference between both measurements is greater than .125 inch, side to side adjustment is necessary (see previous section).
6. If both measurements are between 2.875 inches and 3.125 inches, adjustment is not necessary.
7. If both measurements are less than 2.875 inches or greater than 3.125 inch, adjustment is necessary.
8. To adjust the cut height, place blocks under both sides of the deck so there is slack in the hanger chains. The actual cut height is .5" above the sides of the deck.
9. Loosen the 2 bolts that secure the cut height indicator. (Refer to page 20, Fig 5)
10. If the deck cut height needs raised, slide the cut height indicator forward.
11. If the deck cut height needs lowered, slide the cut height indicator back.
12. With blade cut height correct, securely tighten the bolts.
13. Make sure foot pedal still engages in upper most position.

DECK BELT ADJUSTMENT

(Refer to Fig. 21)

The belt tension is set at the factory, but may need adjustment after the first hour of initial use. Periodically belt should be checked for proper tension, following the procedure below:

1. Position the mower deck in the highest (4 inch) cut height setting.
2. Loosen the lock nut (A) and adjust the draw nut (C) to change belt tension.
3. Increase belt tension by turning the draw nut (C) clockwise and decrease belt tension by turning the draw nut counter-clockwise.
4. The idler spring (B) body length should measure approximately 5.75" for proper belt tension.
5. Tighten the lock nut (A) when the proper belt tension is achieved.



DECK BELT REPLACEMENT

(Refer to Fig. 22)

Major causes of belt failure are improper installation and tension. Before installing a new belt, check spindle shafts and bearings for excessive endplay and wear by moving each spindle shaft side to side and up and down. Be sure they turn smoothly and freely. **Make sure idler is still aligned with spindle sheaves.** Check sheave grooves for cleanliness and wear. If grooves require cleaning, use a cloth moistened with a nonflammable nontoxic degreasing agent or commercial detergent and water.

Avoid excessive force during installation. Do not use tools to pry belt on or roll belt over sheaves. This can cause hidden damage and premature belt failure.

1. Position the mower deck in the lowest (1.5 inch) cut height setting and remove the left and right belt shields.
2. Loosen the lock nut (A) and back off (counterclockwise) the draw nut (B) until tension is released from the old belt (C) and it can be lifted off the deck sheaves.
3. Remove clevis pin (see page 47, item 19) on brake cable clevis yoke (item 18, page 47) at the transmissions, so belt can be removed.
4. Install the new belt following Fig. 22 for proper belt routing.
5. Reinstall brake cable clevis pin and yoke.
6. Reset the belt tension using the procedure in the "Deck Belt Adjustment" section.
7. Re-install the left and right belt shields.




Fig. 22

BLADE SPINDLE ASSEMBLY REMOVAL


(Refer to Fig. 23)

1. It is not necessary to raise machine to remove the blade spindle assembly.
2. Raise the mower deck to the highest position.
3. Remove blade. Be careful handling sharp blades. Use protective material and block securely when removing blades.
4. Lower mower deck to the lowest (1.5 inch) cut height.
5. Remove belt shields.
6. Remove deck belt. See Deck Belt Replacement section above.
7. Remove the top bolt (2) and cup washer (3) from the spindle sheave (1).
8. Mark spindle sheave (1) on the topside so it will not be installed upside down on re-assembly.
9. Remove the spindle sheave (1) with a wheel puller. Make note if you remove any spacers or washers not shown in the illustration, as they will need to be reinstalled as they were removed. Spindle shaft (9) may fall out of the spindle assembly to the ground after removing sheave.
10. Remove square key (16) and bearing shield (4) and save for re-assembly.
11. Remove spindle assembly by removing the six bolts or nuts (17 or 18) that attach the spindle housing (7) to the mower deck. Spindle assembly will fall to the ground if not supported. Protect spindle housing as necessary.

BLADE SPINDLE ASSEMBLY REPAIR/REPLACEMENT

(Refer to Fig. 23)

1. Remove blade spindle assembly as described previously.
2. Press spindle shaft (9) down through bearings (6) and spindle housing (7).
3. Press bearings (6) out of housing (7) or remove from shaft (9) as necessary.
4. Visually inspect parts for excessive wear, corrosion, or damage. Feel parts and rotate bearing races to check for rough spots or excessive wear.
5. Replace with new parts as necessary.
6. Install lower bearing (6) on spindle shaft (9).
7. Install bearing spacer (8) on shaft.
8. Install this assembly into housing (7).
9. Press top bearing (6) onto shaft (9) down against bearing spacer (8).
10. Rotate assembly to make sure shaft moves freely.
11. Secure spindle assembly to the mower deck with the six nuts or bolts (17 or 18). Torque to 21 ft lbs.
12. Install bearing shield (4), square key (16), sheave (1), cup washer (3) and bolt (2) in same sequence as removed. Place a block under the spindle shaft (9) if necessary to hold it up in the spindle housing.
13. Make sure the concave side of the cup washer (3) is down toward the sheave and torque top bolt (2) to 38 ft lbs.
14. Rotate assembly to check for free movement.
15. Install deck belt and belt shields.
16. Inspect bolt. Replace if worn.
17. Install blade and tighten bolt (15) to 50-55 ft lbs.



10128

Fig. 23


TRACTOR ASSEMBLY

Item No.	Order No.	Description	Item No.	Order No.	Description
1	645383	Frame – 200VG4-52 (shown)	23	729768	Panel – Front Bolt On
	645384	Frame – 200VG4-61	24	424294	Grommet
2	100155	Engine – 26 HP Briggs	25	821746	Fuel Hose .187 ID x 41”
3	100207	Air Cleaner	26	821769	Fuel Hose .25 ID x 27”
	100936	Air Filter HD	27	366560	Fuel Filter
	100937	Air Filter Inner	28	280260	Hose Clamp – Spring .25
4	100803	Oil Filter	29	751043	Shield - Heat
5	101197	Muffler	30	729528	Bracket - Console
	101043	Gasket – Muffler	31	693129	Console w/Decal
6	243016	Tap Screw .25 x .625	32	253178	Whiz Bolt .25-20 x .75 Phil. Truss
7	253176	Whiz Bolt .25-20 x .5 Truss	33	253025	Whiz Nut .25-20
8	243565	Bolt .5-13 x 1.25	34	253177	Whiz Bolt .25-20 x .75 Truss
	253066	Whiz Nut .5-13	35	483960	Wheel & Tire 23 x 10.5 x 12
9	254431	Speed Nut .25-20		483445	Wheel Without Tire 12 x 8.5
10	729745	Shield – Rear Guard		482485	Tire 23 x 10.5 x 12
11	142250	Mechanical Choke	36	254472	Lug Nut .5-20
12	605823	Throttle Assembly	37	693216	Fender – Rt. w/Decals
	323643	Cable Assembly	38	693217	Fender – Lt. w/Decals
	722736	Throttle Stop – Heavy Duty	39	822632	Trim – Fender Edge
13	422155	Handle Grip	40	772009	Hole Plug – Work Lamp
14	723062	Mount - Battery	41	150225	Cup Holder
15	604785	Hold Down Strap - 15”	42	259030	Cap Screw .25-20 x .75 Hex
16	722931	Shield – Fuel Tank	43	254436	Nut .25-20 Nylon
17	605805	Fuel Tank Assembly (includes items 18-22)	44	253173	Whiz Bolt .25-20 x .5 Hex
			45	725109	Skid - Plate
18	100212	Cap – Fuel Sealed Tether	46	253203	Whiz Bolt .375-16 x 1
19	363919	Fuel Tube	47	253043	Whiz Nut .375-16
20	101875	Bushing – Fuel Tube	48	424074	Vibration Isolator
21	606830	Fuel Tank Valve Kit	49	253035	Whiz Nut .312-18
22	141139	Gauge – Intake Fuel	50	254432	Nut Plastic Retainer
	424276	Grommet – Fuel Gauge Mount	51	253164	Whiz Bolt - Hex

Item not pictured:
605372

Decal Set – 226VG4 Mower


TRACTOR ASSEMBLY



DRIVE & STEERING ASSEMBLY

Item No.	Order No.	Description	Item No.	Order No.	Description
1	391503	Integrated Transmission Rt.	40	422559	Bearing Sleeve
	130205	Filter Kit			w/Flange .5 x 875
2	391502	Integrated Transmission Lt.	41	422556	Bearing Sleeve
	130205	Filter Kit			w/Flange .5 x .565
3	130232	Hub – Fan	42	422557	Bearing Sleeve .5 x 1
4	130230	Pulley (includes items 5 & 6)	43	243197	Bolt .312-18 x .75
5	130234	Fan	44	643926	Mount – Steering Lever
6	130235	Jam Nut .5-20	45	283324	Spring – Compression
7	130290	Hub Kit (includes item 8)	46	257063	Nylon Washer
	130288	Axle Washer	47	253470	Nut .5-13 Nylon Insert
	254523	Castle Nut 1-20	48	902297	Spacer .625 x .343 x .25
	281860	Woodruff Key .312 x 1	49	265651	Rod End .312-24 Lt. Female
8	130292	Axle Cap	50	243210	Bolt .312-18 x 1.25
9	724268	Arm – Control Rt.	51	265680	Ball Stud
10	724269	Arm – Control Lt.	52	729770	Bracket – Damper Mount Rt.
11	253200	Whiz Bolt .375-16 x .75	53	729771	Bracket – Damper Mount Lt.
12	253043	Whiz Nut .375-16	54	285032	Damper w/Ball Socket – Reverse
13	645117	Brake Rod	55	645748	Steering Lever - Lower Rt.
14	243215	Bolt .312-18 x 1.5	56	645749	Steering Lever - Lower Lt.
15	770004	Lever – Bypass Valve	57	902313	Spacer
16	260648	Cotter Pin .125 x .5	58	253195	Whiz Bolt .312-18 x 1.5
17	415536	Sheave A Groove 4 x 1	59	780171	Rod – Steering Lt./Rt.
18	281582	Square Key .25 x .875	60	265650	Rod End .312-24 Rt. Female
19	388750	Clutch 1"	61	254441	Nut .312-24
20	243470	Bolt .437-20 x 2.5	62	254444	Nut .312-24 Lt. Hand
21	257422	Lock Washer .437	63	243210	Bolt .312-18 x 1.25 Full Thd.
22	725123	Bracket – Anti-Rotation	64	720160	Mount – Steering Switch Rt.
23	422088	Cover – Clutch Bracket	65	720161	Mount – Steering Switch Lt.
24	824478	Idler Arm Assembly	66	183860	Switch – Lever
25	121756	Bearing – Oilite	67	250318	Machine Screw 6-32 x 1
26	121650	Pedestal – Bearing	68	254400	Nut 6-32
27	257062	Washer .5 SAE	69	253176	Whiz Bolt .25-20 x .5
28	393195	Idler 3.46 x .5 x .781	70	253025	Whiz Nut .25-20
29	243580	Bolt .5-13 x 2	71	253245	Whiz Bolt .5-13 x 1.5
30	253066	Whiz Nut .5-13	72	645744	Steering Lever - Upper Rt.
31	284428	Spring – Torsion LH	73	645745	Steering Lever - Upper Lt.
32	729733	Bracket – Belt Tensioner	74	422063	Plug - Nylon .75
33	253192	Whiz Bolt .312-18 x .75	75	422508	Step Bushing
34	243360	Bolt .375-16 x 2.75	76	243035	Bolt .25-20 X 1.5
35	257040	Washer .375	77	253850	Nut .25-20 - Lock
36	381944	Belt HA – 55.1 EL	78	247130	Carriage Bolt .312 x .75
37	253035	Whiz Nut .312-18	79	257019	Washer .25 - Hard
38	604856	Steering Pivot Assembly Rt. (includes items 40-43)	80	252858	Thumb Screw .312-18 3 Prong
39	604857	Steering Pivot Assembly Lt. (includes items 40-43)	81	422179	Grip - Foam
			82	422095	Vinyl Cap

DRIVE & STEERING ASSEMBLY




17092B

ROPS & SEAT ASSEMBLY

Item No.	Order No.	Description	Item No.	Order No.	Description
1	321529	Seat Cushion	27	253193	Whiz Bolt .312-18 x 1
2	321530	Back Cushion w/Logo	28	729767	Cross Member – Seat
3	321523	Arm Rest	29	283516	Seat Spring – Compression
4	723435	Seat Side - Folding Armrest – Rt.	30	422127	Cap – Seat Spring
5	723436	Seat Side - Folding Armrest – Lt.	31	253203	Whiz Bolt .375-16 x 1
6	822630	Seat Edge Trim	32	253043	Whiz Nut .375-16
7	643898	Seat Panel	33	723108	Shield – Fan
	603211	Cable Assembly	34	253173	Whiz Bolt .25-20 x .5 Hex
8	722884	Seat Reinforcement – Raised	35	254431	Speed Nut .25-20
	163295	Decal – Grasshopper Emblem	36	324112	ROPS Tube
9	183871	Seat Switch – Twist	37	243600	Bolt .5-13 x 3
10	644401	Bracket – Seat Pivot Rt.	38	253930	Lock Nut .5-13
11	644402	Bracket – Seat Pivot Lt.	39	729768	Panel – Front Bolt On
12	422565	Sleeve Bearing w/Flange	40	424294	Grommet 2 x 2.25 x .125
13	253175	Whiz Bolt .25-20 x .75	41	253178	Whiz Bolt .25-20 x .75 Phil. Truss
14	724930	Latch – Seat	42	754231	Plate – Seat
15	724929	Mount Bracket – Seat Latch	43	303610	Track Set – Seat
16	730229	Pivot Pin – Seat Latch	44	723075	Slide Stop
17	284408	Spring – Torsion	45	902294	Spacer
18	260606	Ring Cotter .047 x .312	46	253035	Whiz Nut .312-18
19	253176	Whiz Bolt .25-20 x .5	47	754288	Arm Rest – Folding
20	253025	Whiz Nut .25-20	48	243050	Bolt .25-20 x 2.5
21	324200	Seat Belt	49	253440	Nut .25-20 Nylon Insert
22	243551	Bolt .5-13 x .75	50	422508	Step Bushing
23	257063	Nylon Washer .5	51	830325	Speed Nut
24	257062	Washer .5 SAE	52	833542	Cap – Arm Rest Bumper Nut
25	253470	Nut .5-13 Nylon Insert	53	424056	Bumper
26	253191	Whiz Bolt .312-18 x .625	54	257030	Washer .312

ROPS & SEAT ASSEMBLY




18019

BRAKES ASSEMBLY & EXPANSION TANKS


Item No.	Order No.	Description	Item No.	Order No.	Description
1	645103	Brake Lever	19	261236	Clevis Pin .25 x 1
2	422155	Handle Grip	20	260606	Ring Cotter .047 x .312
3	902314	Spacer	21	180605	Clamp – Loom .5
4	263500	External Retainer .5 x .042	22	253176	Whiz Bolt .25-20 x .5 Truss
5	725068	Strap – Brake Cable	23	253025	Whiz Nut .25-20
6	724353	Bracket – Brake Cable	24	421982	Expansion Tank (includes cap)
7	253192	Whiz Bolt .312-18 x .75	25	360083	Fitting – 8 BD Stem/10 MB
8	253035	Whiz Nut .312-18	26	821811	Hose – Hydraulic .5 X 12.5
9	257030	Washer .312	27	280266	Hose Clamp – Spring .5 TOC
10	260608	Ring Cotter .054 x .375	28	424290	Grommet – 1.5 x 2
11	254441	Nut .312-24	29	183894	Switch - Brake
12	257020	Washer .25	30	250258	Machine Screw 10-24 x .75
13	254434	Nut .25-28		254421	Nut 10-24
14	323601	Cable Assembly – Brake	31	253441	Nut .25-28 Nylon Insert
15	283311	Spring – Compression	32	360010	Adapter - Straight Stem 2MB-4BD
16	645117	Brake – Rod	33	821724	Vent Hose .25 ID Clear
17	243215	Bolt .312-18 x 1.5	34	280258	Hose Clamp - Spring
18	265530	Clevis Yoke .25-28 x 2	35	365501	Plug - Tapered .25

BRAKES ASSEMBLY & EXPANSION TANKS




WIRING DIAGRAM - 226VG4

Item No.	Order No.	Description	Item No.	Order No.	Description
	606848	Wiring Assembly	11	181470	Fuse 30 Amp Auto
	161092	Decal – Console	12	181462	Fuse 10 Amp Auto
1	183806	Ignition Switch	13	141551	Hour Meter
	254498	Nylon Nut – Ignition Switch	14	183894	Brake Switch
2	182326	Indicator Light – Brake	15	180125	Battery 12 Volt
3	182327	Indicator Light – Oil		723062	Battery Mount
4	183925	Clutch Switch	16	604785	Battery Hold Down Strap w/Clip
5	183860	Safety Switch – Rt. Steering	17	180290	Battery Cable 30" Black
	720160	Rt. Steering Switch Mount		253193	Ground Bolt .312-18 x 1 Whiz
6	183860	Safety Switch – Lt. Steering		253035	Ground Nut .312-18 Whiz
	720161	Lt. Steering Switch Mount	18	180330	Battery Cable 30" Red
7	183871	Seat Safety Switch		425219	Battery Terminal Boot
8	182262	Work Lamp LED Mini LT Bar FL MT		425215	Alternator Terminal Boot
9	184179	Light Switch (optional)	19	181735	Fuse Holder - Inline
10	184271	Relay w/Mount	20	184911	Connector – 6 Way
			21	422072	Hole Plug



WIRING DIAGRAM - 226VG4




21024

21025

DECK CARRIER LINKAGE

Item No.	Order No.	Description	Item No.	Order No.	Description
1	645340	Footrest	30	732811	Strap – Carrier Linkage
2	424074	Vibration Isolator	31	260608	Ring Cotter .054 x .375
3	253035	Whiz Nut .312-18	32	123522	Bearing Cup
4	645705	Radius Arm – 200VG4/52	33	122522	Bearing – Tapered
	645706	Radius Arm – 200VG4/61	34	257320	Washer – Spring
5	243800	Bolt .625-11 x 1.5	35	254505	Jam Nut .75-16 Nylon Top Lock
6	253970	Lock Nut .625-11	36	481432	Dust Cap
7	645274	Guide – Latch Tube	37	125855	Seal
8	645845	Tube – Height Adjust	38	282615	Spacer
9	730434	Deck Pin – Height Adjust	39	645221	Fork
10	253215	Flange Bolt .375-16 x 5	40	247726	Carriage Bolt .625 x 7
11	253043	Whiz Nut .375-16 Lg Flange	41	257051	Washer .437 SAE
12	423643	Lift Bearing Block	42	603975	Wheel & Tire Assembly
13	774064	Plate – Lift Bearing			13 x 6.5 w/Bearings & Spacer
14	645650	Pivot – Front Carrier	43	423750	Bearing Spacer
15	604513	Spring & Plug Nut Assembly	44	120048	Wheel Bearing
16	243395	Bolt .375-16 x 4.5 Full Thread	45	902415	Spacer
17	902280	Spacer	46	729685	Mount – Height Adjust
18	881154	Shaft – Spring Mount	47	821516	Washer – Nylon 1.5 x .531
19	644644	Pivot Carrier	48	243560	Bolt .5-13 x 1
20	243360	Bolt .375-16 x 2.75	49	253470	Nut .5-13 Nylon Insert
21	902412	Spacer	50	775147	Latch – Deck
22	603741	Rocker Assembly Rt.	51	253192	Whiz Bolt .312-18 x .75
	121764	Oilite Bearing	52	253450	Nut .312-18 Nylon Insert
23	603728	Rocker Assembly Lt.	53	243335	Bolt .375-16 x 1.25
	121764	Oilite Bearing	54	253890	Lock Nut .375-16
24	263529	Retainer – External	55	423696	Spacer – Height Adjustment
25	732586	Adjusting Strap	56	254461	Jam Nut .437-14
26	243205	Bolt .312-18 x 1	57	644467	Foot Pedal
27	820331	Chain - 5 Links	58	253203	Whiz Bolt .375-16 x 1
28	243458	Flange Bolt .437-14 x 1.75	59	257040	Flat Washer .375
29	253058	Whiz Nut .437-14	60	902422	Spacer Axle

DECK CARRIER LINKAGE




18002C

DECK ASSEMBLY - MODEL 226VG4/52

Item No.	Order No.	Description	Item No.	Order No.	Description
1	645189	Deck	37	484230	Wheel – Anti-Scalp
2	824473	Idler Arm Assembly (includes items 3-5)	38	942137	Bearing Tube
3	121756	Bearing - Oilite	39	247310	Carriage Bolt .375-16 x4.25
4	257319	Washer - Spring	40	247130	Carriage Bolt .312 x .75
5	121651	Bearing Pedestal	41	257059	Cupped Washer .5
6	257160	Washer .312 x .531 x 1.625	42	243590	Bolt .5-13 x 2.5
7	393250	Idler 6.0	43	644608	Mulch Plate Rt. (Optional)
8	257062	Washer .5 SAE	44	644609	Mulch Plate Lt. (Optional)
9	243575	Bolt .5-13 x 1.75	45	644058	End Cap (Optional)
10	423670	Stabilizer Cap	46	382111	Belt
11	253067	Nut Flange Spiral Lock .5-13	47	643632	Pivot Mount
12	784057	Tube - Guide	48	604317	Discharge Shield Assembly (includes items 49-53)
13	243038	Bolt .25-20 x 1.75	49	422042	Discharge Shield
14	253025	Whiz Nut .25-20	50	644570	Mount – Discharge Shield
15	422520	Nylon Bearing	51	284406	Spring - Torsion
16	283852	Spring - Extension	52	780650	Pin
17	257040	Washer .375	53	260608	Ring Cotter .054 x .375
18	253043	Whiz Nut .375-16	54	252821	Stud – 3 Prong Head
19	393226	Idler	55	820331	Lift Chain – 5 Links
20	902426	Spacer	56	243458	Bolt .437-14 x 1.75
21	730391	“J” Bolt – Idler Adjustment	57	253058	Whiz Nut .437-14
22	254450	Nut .375-16	58	254431	Speed Nut .25-20
23	645705	Radius Arm	59	254448	Speed Nut .312-18 x .25
24	243800	Bolt .625-11 x 1.5	60	320239	Blade 18” High Lift Notched
25	253970	Lock Nut .625-11		320240	Blade 18” Hi-Low Mulching
26	415902	Sheave		320236	Blade 18” Medium Lift
27	603725	Center Roller Assembly		320238	Blade 18” Contour
28	644512	Lock Pin - Roller	61	751046	Shield – Belt Rt.
29	253192	Whiz Bolt .312-18 x .75	62	751047	Shield – Belt Lt.
30	253035	Whiz Nut .312-18	63	253175	Whiz Bolt .25-20 x .75
31	754203	Roller Mount – Formed Rt.	64	724588	Auxiliary Front Shroud
32	776231	Spacer – Roller Mount	65	253176	Whiz Bolt .25-20 x .5 Truss
33	426122	Roller 3 x 2 x .625	66	902415	Spacer
34	902284	Spacer – Roller Mount	67	729686	Shroud - Discharge Deflector
35	243365	Bolt .375-16 x 3	68	253177	Whiz Bolt .25-20 x .75 Truss
36	645589	Mount – Anti-Scalp Roller Lt. - Tread			


DECK ASSEMBLY - MODEL 226VG4/52



DECK ASSEMBLY - MODEL 226VG4/52R

Item No.	Order No.	Description	Item No.	Order No.	Description
1	645193	Deck	28	644512	Lock Pin - Roller
2	824462	Idler Arm Assembly (includes items 3-5)	29	253192	Whiz Bolt .312-18 x .75
3	121756	Bearing - Oilite	30	253035	Whiz Nut .312-18
4	257319	Washer - Spring	31	754203	Roller Mount – Formed Rt.
5	121651	Bearing Pedestal	32	776231	Spacer – Roller Mount
6	257160	Washer .312 x .531 x 1.625	33	426122	Roller 3 x 2 x .625
7	393250	Idler 6.0	34	902284	Spacer – Roller Mount
8	257062	Washer .5 SAE	35	243360	Bolt .375-16 x 2.75
9	243575	Bolt .5-13 x 1.75	36	645589	Mount – Anti-Scalp Roller Lt. - Tread
10	423670	Stabilizer Cap	37	484230	Wheel – Anti-Scalp
11	253067	Nut Flange Spiral Lock .5-13	38	942137	Bearing Tube
12	784057	Tube - Guide	39	247310	Carriage Bolt .375-16 x 4.25
13	243038	Bolt .25-20 x 1.75	40	247130	Carriage Bolt .312 x .75
14	253025	Whiz Nut .25-20	41	415010	Sheave
15	422520	Nylon Bearing	42	243590	Bolt .5-13 x 2.5
16	283848	Spring - Extension	43	820331	Lift Chain – 5 Links
17	257040	Washer .375	44	243458	Bolt .437-14 x 1.75
18	253043	Whiz Nut .375-16	45	253058	Whiz Nut .437-14
19	424155	Flap - Deck	46	382111	Belt
20	782362	Strap - Flap	47	254431	Speed Nut .25-20
21	730391	“J” Bolt – Idler Adjustment	48	320236	Blade 18” Medium Lift
22	254450	Nut .375-16	49	766026	Grass Thrower
23	645705	Radius Arm	50	751046	Shield – Belt Rt.
24	243800	Bolt .625-11 x 1.5	51	751047	Shield – Belt Lt.
25	253970	Lock Nut .625-11	52	253175	Whiz Bolt .25-20 x .75 Hex
26	415902	Sheave	53	253177	Whiz Bolt .25-20 x .75 Truss
27	603725	Center Roller Assembly	54	243365	Bolt .375-16 x 3.0
			55	422074	Plastic Plug 1.25
			56	902415	Spacer

DECK ASSEMBLY - MODEL 226VG4/52R




15005D

DECK ASSEMBLY - MODEL 226VG4/61

Item No.	Order No.	Description	Item No.	Order No.	Description
1	645194	Deck	38	942137	Bearing Tube
2	824426	Idler Arm Assembly (includes items 3-5)	39	247310	Carriage Bolt .375-16 x 4.25
3	121756	Bearing - Oilite	40	247130	Carriage Bolt .312 x .75
4	257319	Washer - Spring	41	257059	Cupped Washer .5
5	121651	Bearing Pedestal	42	243590	Bolt .5-13 x 2.5
6	257160	Washer .312 x .531 x 1.625	43	644611	Mulch Plate Rt. (Optional)
7	393250	Idler 6.0	44	644610	Mulch Plate Lt. (Optional)
8	257062	Washer .5 SAE	45	644058	End Cap (Optional)
9	243575	Bolt .5-13 x 1.75	46	382099	Belt
10	423670	Stabilizer Cap	47	643632	Pivot Mount
11	253067	Nut Flange Spiral Lock .5-13	48	604317	Discharge Shield Assembly (includes items 49-53)
12	784051	Tube - Guide	49	422042	Discharge Shield
13	243040	Bolt .25-20 x 2	50	644570	Mount – Discharge Shield
14	253025	Whiz Nut .25-20	51	284406	Spring - Torsion
15	422520	Nylon Bearing	52	780650	Pin
16	283848	Spring - Extension	53	260608	Ring Cotter .054 x .375
17	257040	Washer .375	54	252821	Stud – 3 Prong Head
18	253043	Whiz Nut .375-16	55	820320	Lift Chain – 5 Links
19	393226	Idler	56	243458	Bolt .437-14 x 1.75
20	902426	Spacer	57	253058	Whiz Nut .437-14
21	730391	“J” Bolt – Idler Adjustment	58	254431	Speed Nut .25-20
22	254450	Nut .375-16	59	254448	Speed Nut .312-18 x .25
23	645706	Radius Arm	60	320245	Blade 21" High Lift Notched
24	243800	Bolt .625-11 x 1.5		320247	Blade 21" Hi-Low Mulching
25	253970	Lock Nut .625-11		320242	Blade 21" Medium Lift
26	415892	Sheave		320244	Blade 21" Contour
27	603725	Center Roller Assembly	61	751055	Shield – Belt Rt.
28	644512	Lock Pin - Roller	62	751056	Shield – Belt Lt.
29	253192	Whiz Bolt .312-18 x .75	63	253175	Whiz Bolt .25-20 x .75 Hex
30	253035	Whiz Nut .312-18	64	724589	Auxiliary Front Shroud
31	645576	Mount – Anti-scalp Roller Rt.	65	253176	Whiz Bolt .25-20 x .5 Truss
32	723012	Bracket – Idler Guide	66	902415	Spacer
33	426122	Roller 3 x 2 x .625	67	729687	Shroud – Discharge Deflector
34	902284	Spacer – Roller Mount	68	253177	Whiz Bolt .25-20 x .75 Truss
35	243365	Bolt .375-16 x 3	69	257041	Cupped Washer .375
36	645589	Mount – Anti-Scalp Roller Lt. - Tread	70	257024	Washer - Fender .25
37	484230	Wheel – Anti-Scalp			


DECK ASSEMBLY - MODEL 226VG4/61



DECK ASSEMBLY - MODEL 226VG4/61R


Item No.	Order No.	Description	Item No.	Order No.	Description
1	645195	Deck	28	644512	Lock Pin – Roller
2	824462	Idler Arm Assembly (includes item 3-5)	29	253192	Whiz Bolt .312-18 x .75
3	121756	Bearing - Oilite	30	253035	Whiz Nut .312-18
4	257319	Washer - Spring	31	645581	Mount – Anti-scalp Roller Rt.
5	121651	Bearing Pedestal	32	902313	Spacer - .430 x .531 x 1
6	257160	Washer .312 x .531 x 1.625	33	902415	Spacer
7	393250	Idler 6.0	34	253177	Whiz Bolt .25-20 x .75 Truss
8	257062	Washer .5 SAE	35	243360	Bolt .375-16 x 2.75
9	243575	Bolt .5-13 x 1.75	36	645589	Mount – Anti-Scalp Roller Lt. – Tread
10	423670	Stabilizer Cap	37	484230	Wheel – Anti-Scalp
11	253067	Nut – Flange Spiral Lock .5-13	38	942137	Bearing Tube
12	784057	Tube – Guide	39	247310	Carriage Bolt .375-16 x 4.25
13	243038	Bolt .25-20 x 1.75	40	253175	Whiz Bolt .25-20 x .75 Hex
14	253025	Whiz Nut .25-20	41	415010	Sheave
15	422520	Nylon Bearing	42	243590	Bolt .5-13 x 2.5
16	283848	Spring – Extension	43	820331	Lift Chain – 5 Links
17	257040	Washer .375	44	243458	Bolt .437-14 x 1.75
18	253043	Whiz Nut .375-16	45	253058	Whiz Nut .437-14
19	424154	Flap – Deck	46	382102	Belt
20	782364	Strap – Flap	47	254431	Speed Nut .25-20
21	730391	“J” Bolt – Idler Adjustment	48	320242	Blade 21” Medium Lift
22	254450	Nut .375-16	49	766026	Grass Thrower
23	645706	Radius Arm	50	766025	Grass Thrower
24	243800	Bolt .625-11 x 1.5	51	751055	Shield – Belt Rt.
25	253970	Lock Nut .625-11	52	751056	Shield – Belt Lt.
26	415892	Sheave			
27	603725	Center Roller Assembly			

DECK ASSEMBLY - MODEL 226VG4/61R



16031A

BLADE SPINDLE ASSEMBLY




Item No.	Order No.	Description	Item No.	Order No.	Description
1	623700	Blade Spindle Assembly (does not include item 5)	10	259305	Set Screw .25-28 x 1.25 Nylon
2	243331	Bolt .375-24 x 1	11	903643	Bearing Spacer
3	257041	Cupped Washer	12	604775	Spindle Shaft Assembly 5.75
4	721167	Bearing Shield	13	257055	Washer .510 x 2.675 x 10 Ga.
5*	281580	Square Key .25 x .690	14	423680	Deflector Cone
6	110081	Ball Bearing 25 mm – Double Seal	15	421200	Fiber Washer
7	604410	Spindle Housing (includes item 6, 9, & 11)	16	257061	Flat Washer
8	253035	Whiz Nut .312-18	17	257057	Washer .5 – Hardened
9	247141	Stud Bolt .312-18 x 1.25	18	243583	Bolt .5-20 x 2 Grade 8

10115B

*Not included in Spindle Assembly

DISCHARGE SPINDLE ASSEMBLY



Item No.	Order No.	Description	Item No.	Order No.	Description
1	623746	Discharge Spindle Assembly (includes items 2-19)	10	776151	Mount – Blade CCW
2	320520	Spindle Housing	11	243582	Bolt .5-13 x 2 Left Hand
3	110081	Ball Bearing 25 mm – Double Seal	12	766026	Grass Thrower
4	282630	Bearing Spacer	13	243330	Bolt .375-16 x 1
5	605774	Spindle Assembly Left Hand	14	257412	Lock Washer .375-16
6	257106	Washer 1 x 18 Ga.	15	281586	Square Key .25 x 1.125
7	257041	Cupped Washer	16	415010	Sheave
8	243331	Bolt .375-24 x 1	17	253191	Whiz Bolt .312-18 x .625
9	421200	Fiber Washer	18	253044	Flange Nut .375-16 Spiral Lock
			19	882009	Washer .875 x .511 x .150

15001B

